

dragonflite 95

Adjust jib sheet until boom tip is just inside angle part of gunwale.
Adjust topping lift until mark to centre mast is 70mm.
Adjust jib foot depth to 25mm



Adjust boom vang ram until second bottom batten to backstay measures 70mm.
Set mainsail foot to a depth of 25mm.

dragonforce 65

A+rig!

bottom of metal mast ring above the jib hanger.

Adjust boom vang ram until second bottom batten to backstay measures 70mm.

Adjust jib 50mm. to centre

from centreline of the boat to the boom,
40-45mm on the Jib boom
10-20mm on the mainboom.

Adjust jib foot depth to 20-25mm
Set mainsail foot to a depth of 20mm

Tweak the backstay so that the curve of the mast matches the luff curve on the main sail.



This should give you a good base setup for a correctly built rig.

